WARM FRIDGE - PRO

Warm Fridge

Has the fridge been turned off from the socket?

YES → Switch back on & leave for 10 minutes & check. **Did this work?** → YES → SUCCESS!

NO →

Check the kettle lead hasn't been pulled out & the green on/off switch is on & illuminated at the rear of the fridge. If not, reconnect kettle lead & press green switch up to turn on. Leave for 10 minutes & check. **Did this work?**

YES → SUCCESS!

NO →

There is a manual thermostat also at the rear of the fridge, located on the top left corner as you're facing the fridge. Turn anti-clockwise by a quarter to decrease the ambient temperature inside of the fridge. Leave for 10 minutes & check. **Did this work?**

YES → SUCCESS!

NO → Service visit required. Please log through: **service@scanomat.co.uk**